

### **SCRAM Magnet Procedure:**

- **Plug in the modem (if it isn't already) and wait for the alternating red/green lights to stop.**
- **Take a magnet and lay on top of the bracelet number. Hold it there for about 5 seconds (bracelet should eventually vibrate/buzz). Repeat if needed.**
- **After it buzzes the modem red light should eventually come on. Wait until the red light comes on and then eventually goes off.**
- **Unplug modem power for 5 seconds and then plug it back in.**
- **The modem will alternate red/green lights again. After the lights stop alternating you should be done.**